## **RAIL WOOD SCREW**






(Ŧ)

Ó





## NOTE:

Stainless steel screw with coarse thread is used for fastening into wood. The #8 screw is used for mounting the flat base RailEasy™ Tensioners and Swivel Ends. The #10 screw is used for mounting RailEasy™ Straight and Adjustable Sidemounts.